dyson airblade

OWNER'S MANUAL





IMPORTANT SAFETY INFORMATION READ AND SAVE THESE INSTRUCTIONS

The instructions contained within the Installation Template enclosed must be followed carefully when installing the Dyson Airblade™ hand dryer.

Failure to accurately follow the instructions may result in the incorrect operation of the Dyson Airblade™ hand dryer, damage to property and/or personal injury.

Dyson will not be held liable for any damage to property or personal injury as a result of failure to comply with the instructions contained herein.



IMPORTANT SAFETY INFORMATION READ BEFORE PROCEEDING FURTHER

- All electrical installation should be carried out by a qualified electrician in accordance with current local codes or regulations.
- All repairs and service should be carried out by a Dyson service engineer, authorised Dyson service agent or Dyson trained technician.
- 3. The Dyson Airblade™ hand dryer must be earthed.
- 4. Isolate power for installation or servicing.
- 5. Dyson recommends the use of protective clothing/safety glasses when installing/repairing as necessary.
- 6. Trouble free operation and safety can only be guaranteed if genuine Dyson spare parts are used.
- 7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 8. Children should be supervised to ensure they do not play with the appliance.



CAUTION



Do not use the Dyson Airblade™ hand dryer for any purpose other than drying hands.

Risk of electric shock! Do not remove casing or attempt to repair unless unit is being serviced by qualified service personnel. If casing is removed or handled improperly the internal components of the Dyson Airblade™ hand dryer may cause harm or become permanently damaged.

To reduce the risk of fire or electric shock, do not expose the internal mechanisms/components of this unit to moisture.

EUROPEAN DIRECTIVES

The Dyson Airblade™ hand dryer complies with the following European Directives: 93/68/EEC CE Marking Directive 2006/95/EC Low Voltage (Safety) Directive 2004/108/EC EMC Directive

CLEANING ADVICE

Make sure that all surfaces of the Dyson Airblade™ hand dryer are cleaned daily with a soft cloth and non-abrasive, non-caustic cleaning solution, paying particular attention to the seals.

MAINTENANCE ADVICE

Regularly check the air inlet at the base of the Dyson Airblade™ hand dryer to ensure that it is free from dust and debris. If the air inlet gets dirty simply remove dust or debris.

Make sure that all of the Dyson Airblade™ hand dryer's surfaces and the (4) sensor lenses are wiped down daily to maintain uninterrupted operation of the unit.

Also visit the website at www.dysonairblade.com

HOW TO USE

- 1. Insert your hands and the Dyson Airblade™ hand dryer will start automatically.
- 2. Move your hands up and down slowly through the air.

TROUBLESHOOTING

Problem	Action
The Dyson Airblade™ hand dryer fails to start.	Check fuse/circuit breaker is working and that the power supply is connected.
The Dyson Airblade™ hand dryer is turning on and off erratically.	Ensure sensors are clean.
The Dyson Airblade™ hand dryer sometimes cuts out when in use, but resumes operation after a period of time.	Check the air inlet at the base is clean and free of dust. If the air inlet is dusty simply remove dust.
Air is coming out of the front or back of the unit.	Check for and remove any obstructions.

If problems persist please contact the Dyson Helpline on the relevant telephone number, which you can find on page 4 of this manual

Note: If the machine is used continuously for 30 seconds, it will cut out automatically and restart in 5 seconds once hands are removed and reinserted.

Contacting Dyson

The Dyson Helpline can be contacted on the relevant telephone number, which you can find on page 4 of this manual.

When calling the Dyson Helpline, please make sure you have the serial number and the purchase date of the Dyson Airblade™ hand dryer ready. The serial number can be found on the rating plate of your hand dryer.

For further information about the Dyson Airblade™ hand dryer, please visit www.dysonairblade.com

Limited Dyson Guarantee Information

The Dyson Airblade™ hand dryer is covered by a free Dyson 5 year/350,000 drying cycles parts guarantee and Dyson 1 year labour guarantee.

For further information about what is included in the Dyson 5 year/350,000 drying cycles parts guarantee and Dyson 1 year labour guarantee visit www.dysonairblade.com

You can register your Dyson guarantee online at www.dysonairblade.com, by completing the Dyson guarantee form in the box or by calling the Dyson Helpline on the relevant telephone number, which you can find on page 4 of this manual.

Australian Consumer Law

In addition to your rights under the Dyson guarantee, we also provide the following statement as required by the Australian Consumer Law: In Australia, your Dyson Airblade^{to} hand dryer comes with statutory guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have your Dyson Airblade^{to} hand dryer repaired or replaced if it fails to be of acceptable quality and the failure does not amount to a major failure.

€ dyson

Dyson Customer care

UK 0800 345 7788 ROI 01 401 8300 AU 1800 239 766 NZ 0800 397 667 SG 7000 435 7546 QA 4450 8883







The NSF logo is a registered trade mark of NSF International Corporation. The BSF handprint logo is a registered trade mark of the British Skin Foundation. The RSPH logo is a registered trade mark of the Royal Society for Public Health.

www.dysonairblade.com